

>> TODAY WE'RE GONNA BE CHECKING
OUT SOME PRODUCTS THAT ARE ALL
ABOUT YOUR TERRACE AND PATIO.
FIRST UP, THE TERRACE FLOOR.
FOR MOST OF US, THE TERRACE
FLOOR DOESN'T LOOK THAT GREAT,
AND THERE AREN'T A WHOLE LOT OF
OPTIONS WHEN IT COMES TO
COVERING IT.
ONE OPTION YOU MIGHT NOT HAVE
CONSIDERED IS WOOD.
TAKE A LOOK AT THIS.
THIS IS ECO DECKING TILE, AND
THIS IS ACTUAL WOOD TILE.
AND WHAT'S AMAZING ABOUT IT IS
THAT IT'S REALLY, REALLY EASY
TO PUT DOWN.
IT'S ACTUALLY MADE OF SOMETHING
CALLED IPI, WHICH IS ALSO CALLED
BRAZILIAN WALNUT, AND IT'S THREE
TIMES HARDER THAN REDWOOD.
AND IT'S NOT A COMPOSITE AND
THERE'S NO CHEMICALS USED ON IT,
SO IT'S REALLY GREAT FOR THE
ENVIRONMENT.
IT'S ON THIS PLASTIC MATRIX.
YOU CAN SEE RIGHT HERE.
AND THEN THERE'S LITTLE LOCKING
PIECES ON THE SIDE, SO ALL YOU
DO IS SNAP THE PIECES TOGETHER
JUST LIKE THAT.
AND NORMALLY, I DON'T LIKE TO DO

HOW-TO SEGMENTS, BUT THIS IS SO
EASY, I'M GONNA TRY IT OUT.
WOW. THAT WAS EASY.
NO TOOLS, NO SWEAT.
ECO DECKING IS PERFECT FOR ANY
HARD SURFACE, BUT PROBABLY
CONCRETE SLAB IS BEST.
IT COMES IN SEVERAL STYLES.
IT'S RESISTANT TO DECAY AND
INSECT ATTACKS, HARD-WEARING,
LOW-MAINTENANCE, AND COSTS
BETWEEN \$7 AND \$9 A SQUARE FOOT.
NOW, IF YOU'RE NOT WORKING UP
AGAINST A PARAPET WALL LIKE I
WAS RIGHT HERE, THEY ALSO HAVE
THESE EDGE FINISHERS.
SO IF YOU'RE WORKING IN A
BACKYARD SETTING, FOR EXAMPLE,
JUST PUT IT IN LIKE THAT, AND
YOU'VE GOT A NICE, FINISHED
EDGE.
SO WHAT ABOUT THE PLANTS ON YOUR
TERRACE AND PATIO?
WHAT'S A GREAT WAY TO WATER
THEM?
I'VE GOT A SIMPLE SOLUTION.
IT'S REALLY NEAT, VERY EASY TO
DO ALSO.
IT'S CALLED THE RAIN BIRD
GARDENER'S DRIP KIT.
IT'S REALLY DESIGNED FOR A PATIO

SITUATION TO HANDLE ABOUT 75

SQUARE FEET, BUT IT WORKS GREAT
ON A TERRACE, TOO.

I'M GONNA GIVE YOU A LITTLE MINI
DEMONSTRATION HERE.

YOU CUT THIS MAIN TUBE FOR AS
LONG AS YOU WANT IT.

YOU ADD THIS ADAPTER END TO ONE
END, AND THEN YOU SEAL UP THE
OTHER END.

THEN STRETCH THE HALF-INCH
PERIPHERY TUBE AROUND THE
TERRACE.

THEN MARK WHERE YOU'RE GOING TO
PLACE EACH POTTED PLANT.

THEN PUT A SPOUT WATER ADMITTER
ONTO THE PURPLE ADMITTER TOOL.

USE THE TOOL TO PUNCH THE SPOUT
WATER ADMITTER INTO THE
PERIPHERY HOSE WHERE YOU MARKED
IT.

THEN REPEAT THE PROCESS FOR EACH
POTTED PLANT.

ONCE THAT'S DONE, MEASURE OUT
HOW MUCH OF THE QUARTER-INCH
TUBING YOU'LL NEED TO GO FROM
THE PERIPHERY HOSE TO YOUR
PLANT.

CUT THE QUARTER-INCH TUBE TO THE
PROPER LENGTH.

THEN ATTACH ONE END OF THE
QUARTER-INCH TUBE TO THE SPOUT

WATER ADMITTER THAT'S ALREADY IN
THE PERIPHERY TUBE.

TO THE OTHER END, ATTACH A BUG
GUARD TO PREVENT BUGS AND DEBRIS
FROM CLOGGING UP THE TUBING.

NEXT PUT A TUBING STAKE INTO THE
POTTED PLANT, THEN SNAP THE
QUARTER-INCH TUBING INTO THE
STAKE AND CAP THE STAKE.

NOW REPEAT EACH OF THESE STEPS
FOR EACH POTTED PLANT.

WHEN YOU'RE DONE, TURN ON THE
WATER, AND YOU'LL SEE A SLOW
DRIP FROM EACH OF THE
QUARTER-INCH TUBINGS AT EACH
PLANT.

AND FINALLY YOU'VE GOT A
BEAUTIFUL NEW FLOOR, HAPPY
PLANTS, BUT THERE'S SOMETHING
MISSING.

HOW ABOUT MUSIC?

THAT'S WHAT THIS IS ALL ABOUT.

IT'S FROM ADVENT, AND IT'S A
WIRELESS SPEAKER.

YOU PLUG THE TRANSMITTER INTO
YOUR MUSIC SOURCE, AND THEN THE
SPEAKER IS BATTERY-OPERATED.

OUT HERE, JUST TURN IT ON...

[MUSIC PLAYS]

...AND YOU'VE GOT BEAUTIFUL
MUSIC.

YHH 124 CC-4 City Dwellers - Terrace.txt

NOW, ADD A COLD BEVERAGE, AND IT

DOESN'T GET BETTER THAN THIS.

NOW, FOR MORE INFORMATION ON

ANYTHING I SHOWED YOU TODAY, GO

TO OUR WEBSITE,

yourhouseandhome.tv.

>> Teresa: "YOUR HOUSE & HOME"

WILL BE RIGHT BACK.

>> Announcer: PROMOTIONAL FEES

PAID BY THE FOLLOWING...